

Early Ford Parts

Right hand Drive Parts List.

A Comprehensive listing of original and reproduction parts.

Please note: Not all parts are manufactured. Not all parts can be guaranteed to be stocked at any one time.

#Front floor mat. Original Spatter Pattern.

#Pedal mat.

#Clutch pedal.

#Brake pedal.

#Bellhousing for 1928 multi-plate clutch.

#Bellhousing for 1930 single plate clutch.

#Pedal shaft from bellhousing.

#Shaft collar.

#Floor board sets 'AR'.

#Floor board sets 1928/29.

#Floor board sets 1930.

#Inlet manifold.

#Steering box 7 tooth. (Inc. all parts associated with the steering box.)

#Steering box 2 tooth. (Inc. all parts associated with the steering box.)

#Drag link.

#Right hand steering ball joints.

#Left hand steering ball joint.

#Drop arm from steering box.

#Gearbox top 1928. 'AR'.

#Gearbox top 1928.

#Gearbox top 1930

#Gearlever 1928/29.

#Gearlever 1930.

#Stop light switch 1928/29.

#Right hand tail light bracket 28/29. Cast.

#Right hand tail light bracket 1930. Pressed.

#Mark 1 Aircleaner.

#Mark 2 Aircleaner.

#Throttle and advance and control rods.

#Accelerator mechanism arms, clamp to steering column.

#Loom 2 bulb

#Loom 1 bulb.

#Fuel tank 1928/29.

#Fuel tank 1930. For early dash.

#Fuel tank 1930. For later dash.

#Robertson screws used throughout most vehicles.

#Brake equalizer bar 1929/1930.

#Starter motor switch activating arm. (Bolts to back of block.)

#Exhaust manifold clamp. Special clamp made for right hand drive. Made in New Zealand.

#Gear lever plate 1930.

#Gear knob. (different shape).

Rear vision mirror.

Prices upon application.

